

QUICK GUIDE


Connecting your PTT Voice Responder to GroupTalk (iOS) (EN)



A

Pairing your PTT Voice Responder with your iPhone via Bluetooth

1. Turn on your PTT Voice Responder by holding down the Power button for more than 3 seconds. After it is on, a blinking green light will indicate that the device is ready for pairing.
2. Turn on your iPhone's Bluetooth by going to: Settings → Bluetooth → Turn on.
3. Pair your PTT Voice Responder to your iPhone by selecting it from the Devices list. To know which device to select from the list, check the unique friendly name on the back of your Voice Responder. Once it has successfully paired, a blue light will begin blinking on your device.





NOTE: The Voice Responder can only be paired with one device at a time. If you want to pair it to another device you need to perform an **Unpairing/ Software reset** by pressing and holding both soft buttons and both PTT buttons simultaneously, until the LED blinks once in yellow.



B

Installing the GroupTalk application into your iPhone

4. From your iPhone, go to the iTunes App Store, search for the application called **GroupTalk** and install it.
5. Open the application and setup your account with the details provided by GroupTalk or your group administrator.




If you have already downloaded the GroupTalk application and have an existing and active account, simply log in.



C

Enabling your PTT Voice Responder within GroupTalk

6. In the GroupTalk application, select the 'Settings' tab.
7. From the list that appears, first make sure that 'Bluetooth audio' is on (green).
8. Then select 'Bluetooth 4.0 buttons'.
9. Click on the name of your device and select 'Use device'.



The PTT Voice Responder will now be linked to the application, and will automatically connect whenever GroupTalk is online.

For more information on how to use the GroupTalk application please visit their website www.grouptalk.com or take a look at their user guides from www.grouptalk.com/support



AINA PTT Voice Responder's main button functions when connected to GroupTalk



Button	Function
Power ON/ OFF	Press for more than 3 seconds to turn the device on/off.
Primary/ Secondary PTT	Press and hold to speak. Release when you are done.
Emergency	Press and hold the Emergency button for about three seconds, until you hear two short beeps and the emergency alarm is activated. This feature must be configured by your administrator for your account before it will be available and visible in the app. To set this up, please visit www.grouptalk.com/support
Volume buttons	Press and hold to increase/ decrease the speaker's volume.
Soft buttons	These buttons have multiple functions: <ul style="list-style-type: none"> • Press and hold the left soft button to (de)activate the LED. • Press and hold both soft buttons to (de)activate Covert Mode in which LED indications are suppressed and audio annunciations are only delivered through a headset.

Visit www.aina-wireless.com to find additional accessories, an extended user manual of the AINA PTT Voice Responder and more user guides. If you have any further questions, you can also email us at: info@aina-wireless.com

