

QUICK GUIDE


Connecting your PTT Voice Responder
to TangoTango (iOS) (EN)



A

Pairing your PTT Voice Responder with your iPhone via Bluetooth

1. Turn on your PTT Voice Responder by holding down the Power button for more than 3 seconds. After it is on, a blinking green light will indicate that the device is ready for pairing.
2. Turn on your iPhone's Bluetooth by going to: Settings → Bluetooth → Turn on.
3. Pair your PTT Voice Responder to your iPhone by selecting it from the Devices list. To know which device to select from the list, check the unique friendly name on the back of your Voice Responder. Once it has successfully paired, a blue light will begin blinking on your device.





NOTE: The Voice Responder can only be paired with one device at a time. If you want to pair it to another device you need to perform an **Unpairing/ Software reset** by pressing and holding both soft buttons and both PTT buttons simultaneously, until the LED blinks once in yellow.



B

Enabling your PTT Voice Responder's speaker within TangoTango

4. In the TangoTango application, select 'More' displayed on the top right corner.
5. Select 'Settings'.
6. Near the bottom of the list turn on 'Allow Bluetooth Audio'.
7. Finally, select 'Done' displayed on the top right corner.




For more information on how to use the TangoTango application please visit their website: tangotango.co



C

Enabling your PTT Voice Responder's microphone within TangoTango

8. In the TangoTango application, select “More” displayed on the top right corner.
9. Select ‘Settings’.
10. Near the top of the list, select “Headset Sound Profile”.
11. From the bottom of the list, select “Headset Type” and from the list that appears, select “Bluetooth PTT”.
12. Select “Done” displayed on the top right corner.



For more information on how to use the TangoTango application please visit their website: tangotango.co



AINA PTT Voice Responder's main button functions when connected to TangoTango



Button	Function
Power ON/ OFF	Press for more than 3 seconds to turn the device on/off.
Primary/ Secondary PTT	Press and hold to speak. Release when you are done.
Volume buttons	Press and hold to increase/ decrease the speaker's volume.
Soft buttons	<p>These buttons have multiple functions:</p> <ul style="list-style-type: none"> Press and hold the left soft button to (de)activate the LED. Press and hold both soft buttons to (de)activate Covert Mode in which LED indications are suppressed and audio annunciations are only delivered through a headset.

Visit www.aina-wireless.com to find additional accessories, an extended user manual of the AINA PTT Voice Responder and more user guides. If you have any further questions, you can also email us at: info@aina-wireless.com

